


JACKSON

Model 5472 Harness Cage



INSTRUCTION SHEET AND PARTS LIST

2/2024



Read and understand this material before operating or servicing the Harness Cage. Failure to understand how to safely operate and service this Harness Cage may result in injury or property damage.



This manual is free of charge. All personnel who operate the Harness Cage should have a copy of this manual and read and understand its contents. To request a copy, call or write to the address below.

JACKSON TOOL • P. O. BOX 5701 • GREENVILLE, SC 29606
877-522-8995 or 864-721-4235 • FAX 864-721-4236 • www.jacksonstoolinc.com


ASSEMBLED VIEWS

⚠ CAUTION

- Only roll on a firm, flat, smooth surface
- Ensure the shelf is securely fastened prior to use



EXPLODED VIEW



PARTS LIST

ITEM NO.	PART#	DESCRIPTION	QTY.
1.....	5472-133.....	CAGE WELDMENT.....	1
2.....	5400-138.....	DOOR-LEFT, WITH MESH.....	1
3.....	5400-136.....	DOOR-RIGHT WITH MESH AND LOCK.....	1
4.....	5633WC-019.....	LATCH.....	1
5.....	5633WC-026.....	BOTTOM ROD.....	1
6.....	5633WC-032.....	TOP ROD WELDMENT.....	1
7.....	5633WC-043.....	SCREW-HEX HEAD CAP (1/4-20 x 1").....	3
8.....	5633WC-044.....	NUT-HEX 1/4"-20 NYLON INSERT.....	4
9.....	224-141.....	WASHER-FLAT USS 1/4" ZINC.....	2
10.....	5633WC-048.....	RIVET-DOOR ASSEMBLY (NOT SHOWN).....	24
11.....	506-1.....	CASTER - SWIVEL.....	2
12.....	506-2.....	CASTER - FIXED.....	2
13.....	5633WC-042.....	SCREW-HEX HEAD CAP GR5 ZINC (3/8-16 x 1.25).....	12
14.....	5633WC-041.....	WASHER-FLAT 3/8 (USS) ZINC.....	12
15.....	536-5.....	3/8 LOCK WASHER.....	12
16.....	5633WC-040.....	3/8 HEX NUT.....	12
17.....	5633WC-1.....	PLUG-CAP 2 x 2.....	4